



www.pres-on.com

TIPS

- Use a sharp knife or scissors.
- Make sure your hands are clean. Fingerprints may show through.
- Touch the adhesive as little as possible.
- To better adhere photos, fabric and paper to the mounting board, place the liner paper over the object and use a smooth flat object like a credit card or squeegee to rub.

PRES-ON® Score-N-Snap™ Plastic

INTRODUCTION

Pres-On® Self-Stick™ Score-N-Snap Plastic™ is an exciting product to work with. Score it with a craft knife and snap it apart, or cut it with sharp scissors. **Score-N-Snap Plastic™** can be bent into different shapes and will stick to itself.

Score-N-Snap Plastic™ with Hi-Tack Adhesive is for fabrics or paper — fabrics are repositionable, but paper is not.

Lo-Tack Adhesive is designed for use with paper, and is repositionable. Both are available in white or black, in a wide range of sizes.

USEFUL FOR HOME, BUSINESS & SCHOOL PROJECTS

Score-N-Snap Plastic is great for mounting photos, pictures from magazines, catalogs, and calendars. Use a computer to design and print your message, adhere it to the plastic, score and snap it apart... In minutes you have a sign!

Adhesive-coated **Score-N-Snap Plastic** is ideal for mounting fabrics — for home decor, frames, placemats, wallhangings, etc. **Score-N-Snap Plastic** works well with glitter, sand, tiny marbles, beads, light-weight stones or glass pieces, tissue papers, napkins, gift papers, and much more.

FOR ADDITIONAL INFO OR TO
PLACE AN ORDER CALL
800-323-1745